









64 4.19.24 We are very happy to understand that fiber optics are coming to our community. Ahead of the actual construction, we are seeing what appears to be spray painted markings in the right of way and on the roads. Is there an explanation that can help us know what these things mean? This question is related to the previous question, # 63. Yes, there is a great resource available, copied below for your use. It is all associated with the Arizona811 system, which has historically been called "Blue Staking". It is required under law, as a safety precaution, prior to digging in order to safeguard against the possibility of hitting buried utility lines. The website is www.Arizona811.com.

**Contact Arizona 811 two working days before you dig!
It's free. It's easy. It's the law.**

Uniform Color Code for Marking Underground Facilities

-  Proposed Excavation
-  Temporary Survey
-  Electric Power
-  Gas, Oil, Dangerous Materials, Products Lines
-  Communications, Cable TV, Fiber Optics (w/F)
-  Water Systems, Slurry Pipelines
-  Reclaimed Water
-  Sanitary Sewer Systems

**Create tickets for digging or
design anytime with E-Stake**



**Know what's below.
Call 811 or click Arizona811.com
before you dig.**

Learn more at www.Arizona811.com